



A modern, chrome-finished kitchen faucet with a high-arc spout and a single-lever handle. The faucet is shown against a plain white background. The handle is on the left, and the spout extends to the right. The faucet has a sleek, contemporary design with a polished chrome finish.

- Colour: chrom
- integrierte Vorabspernung
- Einlochmontage
- GROHE SilkMove 46 mm Keramikkartusche
- GROHE Long-Life Oberfläche
- variabel einstellbare Mengenbegrenzung
- schwenkbarer Rohrauslauf
- mit Anschlagbegrenzung
- Auslauf mit Mousseur
- Schnell-Montage-System
- flexible Anschlusschläuche



33 312 000 EURODISC EINHAND-SPÜLTISCHBATTERIE, 1/2"



ERSATZTEILE, Januar 1998 – now

- 1: Hebel (Bestell-Nr. 46439000)
- 1.1: Befestigungssatz (Bestell-Nr. 46335000)
- 2: Kappe (Bestell-Nr. 46127000)
- 3: Kartusche (Bestell-Nr. 46048000)
- 4: Dichtungsset (Bestell-Nr. 46429K00)
- 5: Mousseur (Bestell-Nr. 13928000)
- 5.1: Siebeinsatz, Mousseur M22+M24x1 (Bestell-Nr. 45002000)
- 6: Auslauf 234 x 156 (Bestell-Nr. 06417000)
- 7: Keramik-Kartusche (Bestell-Nr. 46318000)
- 8: Absperrgriff (Bestell-Nr. 46450000)
- 8.1: Schnappeinsatz (Bestell-Nr. 0538600M)
- 9: Gegenverschraubung (Bestell-Nr. 46249000)
- 10: Anschlußschlauch, 470 (Bestell-Nr. 45484000)
- 11: Demontageschlüssel (Bestell-Nr. 19132000)*

* Sonderzubehör